

RDM Communicator™

The RDM communicator is a sleek tool box for remote setting of Robe and Anolis fixtures via DMX link. With it's main purpose - setting up fixture options (DMX address, DMX mode...etc) for Anolis non-display products like ArcPad Xtreme, ArcPad 48 Integral, it offers quick and elegant device presetting and maintenance. RDM communicator doesn't require any computer knowledge or laptop for it's function. It's standard RDM protocol implementation allows remote control of any Robe or Anolis fixtures as well as any RDM enabled device such are DMX splitters, RDM enabled Wifi transmitters or RDM enabled utilities.



Main features

- Setting user options and reading fixture information of any Robe fixture with RDM protocol
- Possibility to set multiple fixtures on DMX line
- Graphic touch screen
- 4 operational buttons
- Battery operated

Supported functions

- DMX address setting
- DMX mode selecting
- Pan/Tilt settings -> Personality settings
- Fixture display setting
- Fixture reset
- Fixture identification
- Readouts (device hours, lamp hours, lamp strikes, software version, device label)
- Lamp on/off
- No extra PSU needed (only for charging the battery)
- Rugged aluminium housing
- 3-pin/5-pin XLR input
- Dimensions (h x w x d): 53mm x 98mm x 152mm
- Weight: 0.4kg



communication

ROBE®

www.rob.e.cz

Head office: ROBE lighting s. r. o. | Házovice 2090 | 756 61 Rožnov pod Radhoštěm | Czech Republic | Tel.: +420 571 751 500 | Fax: +420 571 751 515 | E-mail: robe@robe.cz
Factory: ROBE lighting s. r. o. | Palackého 416 | 757 01 Valašské Meziříčí | Czech Republic | Tel.: +420 571 751 500 | Fax: +420 571 751 515 | E-mail: robe@robe.cz | **UK:** ROBE UK Ltd. | Northampton, UK | Tel.: 01604 741000 | E-mail: info@robeuk.com | **America:** ROBE Lighting Inc. | 12349SW 53rd Street, Suite 202 | Cooper City | FL, USA | Tel.: +1 954 680 1901 | E-mail: info@robelighting.com
South-East Asia: ROBE S.E.A. | Singapore | Tel.: +65 8118 6665 | E-mail: info@robe-sea.com | **United Arab Emirates:** Makateb Business Centre | Makeen Tower, Corner of 9th and 10th Street Abu Dhabi | UAE | Tel.: +971 2 657 3461 | E-mail: elie.battah@robe.cz | **Russia and CIS** | Taganskaya str. 26 – 1 – 72 | 109004 Moscow | Russia | Tel: + 7 495 504 9569 | E-mail: boris.krylov@robe.ru
Central and South America | Galicia 1200 ap 303 | 1100 Montevideo | Uruguay | Tel.: +5982 2900 67 47 | Email: guillermo.traverso@robe.cz